

# The TF20 microscope interfaces

## The microscope console

**Location:** right in front of you on the desk

**Role:** It provides direct control of some of the most important microscope parts:

- Magnification
  - Electron dose: spot size (C1 lens) and beam spread (C2 lens)
  - Focus (objective lens current)
  - Stage position (with the joystick and Z buttons)
  - Beam position (with the trackball)
  - and many other actions through the programmable switches (L/R1-2-3) and Multifunction X/Y knobs.
- 

## Gatan DigitalMicrograph User Interface (DM)

**Location:** On the left screen

**Role:** It controls the US10001 Camera.

- the user will use it to :
    - prepare Dark and gain references.
    - during screening, to acquire images in continuous mode.
- 

## SerialEM User Interface (SEM)

**Location:** On the right screen

**Role:** It provides camera/microscope commands to allow the user to screen its grids and setup an automated data collection.

- **The beginner user will use it to:**
  - record the Atlases.
  - select squares and prepare the square maps at eucentric height.
  - select targets (position).
  - screen targets at higher magnification (as single image or montage).
  - center the different beam modes all together on the camera axis.
- **The expert user will use it to:**
  - perform all the actions described above.

- perform beam corrections (astigmatism, coma-free).
- perform calibrations.

---

## The TEM User Interface (TEM)

- The user will use it to:
- The expert user will use it to:

---

## The TEM User Interface (TEM)

Location: On left screen

Role: It controls all the microscope systems.

It is divided into 4 zones:

The beginner user will use it to:  
The expert user will use it to:

The FluCam User Interface (FC)

Location: On the right screen

Role: It allows the visualization of the electron beam and the sample image.

The beginner user will use it to:  
The expert user will use it to:

From:

<https://bsi.inscog.eu/> - **BSI wiki**

Permanent link:

[https://bsi.inscog.eu/doku.php?id=tf20\\_interface&rev=1679502323](https://bsi.inscog.eu/doku.php?id=tf20_interface&rev=1679502323)

Last update: **2023/11/01 20:15**

