


# Vitrobot procedure

The Vitrobot<sup>TM</sup> (Vitrification Robot) is a fully PC-controlled device for vitrification (= rapid cooling) of aqueous samples



## Before starting

- fill a dried 5 L tank with liquid nitrogen
- label the grid boxes
- check a number of points:
  - plasma cleaner is reserved
  - EM\_grids grids are available and present in sufficient number
  - all part of the coolant container are dry
  - close climate chamber's door if open
  - Paper filter clipping ring are not missing

## Starting up the vitrobot

- 1. [Switching on vitrobot](#)
  - Press the hard lock switch on the backside of the machine



- The Vitrobot User Interface page will appear after a few seconds.



- 2. check humidifier beaker state in humidity panel

### Humidifier beaker ready to work



### Humidifier beaker empty need to be refilled



- 3. if EMPTY refill it with distilled water


### **Use ONLY distilled water**

- 1. Fill a syringe with 60 ml distilled water
- 2. inject the whole volume through the plastic tube at the bottom part of the humidifier
- 3. When removing the syringe from the tube, be careful not to tear it from its location




## Set humidity and temperature parameters in climate chamber

- 1. hermetically close the chamber by rotating the white latch
- 2. adjust desired temperature value
  - : to any value between 4 and 60°
    - the actual temperature value is displayed in red
    - set to any desired value with + and buttons in temperature panel




- 3. adjust desired humidity value
  - 96-100 % generally
    - the current humidity is displayed in blue
    - set to desired value with + and - buttons in humidify panel



- 4. wait until desired temperature is reached to enable the humidity switchbox to start press ON/OFF switch

1. Desired temperature value reached

2. Press ON to start evaporation



- take advantages from this waiting time to start next step :

### load grids inside the plasma cleaner

- 1. [switch on plasma cleaner if not started](#)
  - If stopped, press the hard lock switch on the backside of the machine,
  - Press CLEAR to initialize the vaccum system

Not Initialized State  
Just after swithing on



Ready State  
fishione ready for use



- fishione started with chamber locked under vaccum
- READY / HIGH VACCUM messages




- 2. press Vent Lock to bring the chamber under atmospheric pressure
  - State is reached when message Lock At Atmosphere appears


From now on IMPERATIVELY **wears gloves**

- 3. Open chamber and make sure the seal remains in place
  - a. unlock the rod by pushing the button on it
  - b. pull the rod upwards to lift the cover
  - b. move the cover on the side around its axis
  - c. if necessary put back the seal in place.
    - It can either stick on the cover or come out of its channel

### Chamber closed




### Chamber opened



**Seal in place**



- 4. retrieve the metallic drawer and place it on the table
  - the support carrying the drawer can be taken out by lifting it by the rod.
  - Be sure to keep the table horizontal so as not to slide the drawer
  - the metallic drawer is **ALWAYS stored in the chamber**
- 5. close the door to prevent dust contamination inside the chamber
- 6. place EM\_grids inside the metallic drawer
  - remove the cover of the metallic drawer by sliding
  - place EM\_grids inside
  - generally sets of 4 to 8 **IDENTICAL** grids are loaded simultaneously
  - close the drawer by putting back in place the cover

- put back in place the closed drawer on the support table
- generally sets of 4 to 8 **IDENTICAL** grids are loaded simultaneously
- 7. **open the door and make sure the seal remains in place**
  - a. if necessary put the seal back in place
    - It can either stick to the cover or come out of its channel
  - b. clean it just by passing your finger
- 8. put back in place the metallic drawer inside the chamber
  - on the platform **NOT on the inlet pump**



- 9. **close the door**
  - a. be sure the seal is in place and clean (see part.7)
  - b. move the lid around its axis to bring it over the opening of the chamber
  - c. unlock the rod by pushing the button
  - d. gently allow the lid to slide down
- 10. press VACCUM to bring the chamber under vacuum
  - State reached when message "HIGH VACCUM" appears

**Assemble different part of the coolant container like showing below**



- **legende**

- A : central ethane cup
- B : grid storage device
- C : spindle
- D : Ice contamination protective sleeve (optional)
- E : outer nitrogen container

## Cooling down the coolant container

- 1. Fill coolant container with liquid nitrogen both central ethane cup and outer part
- 2. Wait for complete evaporation of the remaining nitrogen in the central part
- 3. up to now continuously fill the outer part to maintain the Nitrogen level
- 4. wait 10 to 15 min for system to equilibrate
- 4. then liquefy the ethane in the central cup already cooled to liquid nitrogen temperature

Ethane is liquefied by flowing a stream of gas through plastic tubing connected to an ethane flask into the central cup

- 5. let ethane start to solidify for few seconds

appearance of a white solid rim around the wall container indicates that ethane starts to solidify

- 6. then remove the spindle

solidified ethane makes stick together the spindle and the ethane cup. Thawing the frozen ethane by placing the second ethane cup on the spindle for 10sec is the more careful way to remove it

## Mounting the filter papers

- **IMPORTANT always wears gloves**
- attach the blotting papers to the the blot pad by using the with clipping ring

A way to keep the **soaking time reproducible** is do this operation always the same time before freezing

## Set freezing condition

\* Now vitrobot is ready for freezing before Do it when you are almost ready to freeze to keep the soaking time as reproducible as possible

===== At this point already is ready for freezing =====

At this point already is ready for freezing:  
climate chamber is equilibrated in temperature and humidity.  
Filter paper are mounted and soaking time is controlled  
ethane is liquefied  
Grids are loaded and ready to be plasma cleaned

## plasma clean grids

- Grids are already loaded inside the plasma cleaner
  - [if not yet done](#)

see part

### load grids inside the plasma cleaner

- set desired plasma cleaning parameters :gas mixture/gas flow power
  - [commonly settings 80-20-0 are used](#)
    - Gas mix: 80/20 oxy/Ar, power 34%
- \* The setup TABS store preset parameters



\* Gas Mix and plasma TABS show preset values

- adjust the plasma cleaning time with up/down arrows head and press set
  - commonly 90 s are used
- press START to apply plasma on grids

## Preparation of the grid

- A glow discharge grids is attached to the tweezers

## Start freezing

\* ++ Do it when you are almost ready to freeze to keep the soaking time as reproducible as possible|<div>

Decire </div>==== Mounting the filter papers, IMPERATIVELY wear gloves ==== \* ++ Do it when you are almost ready to freeze to keep the soaking time as reproducible as possible

## Decrire

From:

<https://bsi.inscog.eu/> - **BSI wiki**

Permanent link:

<https://bsi.inscog.eu/doku.php?id=vitrobot&rev=1673517618>

Last update: **2023/11/01 20:15**

